
# Safety directions / Instruction manual Antonino Wall Lamp Scudo



SERAX

#### WWW.SERAX.COM

Veldkant 21, 2550 Kontich, Belgium - Tel. +32 3 458 05 82

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference.

- The luminaires may only be installed by authorized and qualified technicians according the valid regulations for electrical installation. 1.
- 2. Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture can come into contact with any areas of the terminal connections or voltage control parts.
- The electrical supply must be switched off at the outset, preferably by means of a switch in the distribution box, before any installation, 3. maintenance or repair work is undertaken.
- 4. Exterior light must not be installed during rain.
- 5. Take account of the minimal separation distance from other objects and the room required around the fitting.
- 6. If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- 7. Clamping screws in electrical connections must be adequately tightened. This is particularly the case with 12V low voltage conductors.
- 8. When replacing a halogen lamp, wait for it to cool, for a minimum of 5 minutes.
- 9. Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components.
- 10. Take account of all available technical information.
- 11. Take note of the symbols when connecting wires:

N = Neutral L = Live


🕒 = Earth

- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service 12. agent or a similar qualified person in order to avoid a hazard.
- 13. Meaning of symbols:

থি	For indoor use only, where direct contact with water is impossible
$\bigcirc$	Protection class 1: the fitting must be earthed
	Protection class 2: the fitting is double insulated and does not require earthing
	Protection class 3: the fitting is low voltage
0,5m	Observe the indicated minimum distance between the lamp and the illuminated materials/objects
R	Only the self-screening halogen illuminants should be used with the luminaire
j/F	Strip the wire to the indicated length
	Connect using the specified cable
	The armature can be used in combination with a dimmer. Consult the sales outlet for the correct type of dimmer (important in the case of 12V fittings)
Max 25W 1xE27	
25W	type of dimmer (important in the case of 12V fittings)
25W	type of dimmer (important in the case of 12V fittings) The maximum wattage indicated in each lighting unit, for example, must not be exceeded This luminaire cannot be disposed together with normal domestic waste in standard rubbish bin, but
25W 1xE27	type of dimmer (important in the case of 12V fittings) The maximum wattage indicated in each lighting unit, for example, must not be exceeded This luminaire cannot be disposed together with normal domestic waste in standard rubbish bin, but you have to bring it to a staging area for electrical waste

# Safety directions / Instruction manual **Antonino Wall Lamp Scudo**

RUST B7219013



WWW.SERAX.COM

Veldkant 21, 2550 Kontich, Belgium - Tel. +32 3 458 05 82

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference.

- The luminaires may only be installed by authorized and qualified technicians according the valid regulations for electrical installation. 1.
- 2. Maintenance of the luminaires is limited to their surfaces. During maintenance no moisture can come into contact with any areas of the terminal connections or voltage control parts.
- The electrical supply must be switched off at the outset, preferably by means of a switch in the distribution box, before any installation, 3. maintenance or repair work is undertaken.
- 4. Exterior light must not be installed during rain.
- 5. Take account of the minimal separation distance from other objects and the room required around the fitting.
- 6. If in any doubt, consult a professional, taking local installation requirements into account. Some countries stipulate that lighting may be installed only by registered installers.
- 7. Clamping screws in electrical connections must be adequately tightened. This is particularly the case with 12V low voltage conductors.
- 8. When replacing a halogen lamp, wait for it to cool, for a minimum of 5 minutes.
- 9. Clean with a clean, dry cloth or brush, use no solvents or abrasives. Avoid dampness on all electrical components.
- 10. Take account of all available technical information.
- Take note of the symbols when connecting wires: 11.

N = Neutral L = Live

- = Earth
- If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service 12. agent or a similar qualified person in order to avoid a hazard.
- 13. Meaning of symbols:


ŵ	For indoor use only, where direct contact with water is impossible
	Protection class 1: the fitting must be earthed
	Protection class 2: the fitting is double insulated and does not require earthing
	Protection class 3: the fitting is low voltage
0,5m	Observe the indicated minimum distance between the lamp and the illuminated materials/objects
R	Only the self-screening halogen illuminants should be used with the luminaire
1	Strip the wire to the indicated length
Ð	Connect using the specified cable
	The armature can be used in combination with a dimmer. Consult the sales outlet for the correct type of dimmer (important in the case of 12V fittings)
Max 25W 1xE27	The maximum wattage indicated in each lighting unit, for example, must not be exceeded
X	This luminaire cannot be disposed together with normal domestic waste in standard rubbish bin, but you have to bring it to a staging area for electrical waste
220-240V 50-60HZ	This luminaire was designed to work only with the indicated voltage
Œ	

## Safety directions / Instruction manual Antonino Wall / Table Lamp Ombre


 BLACK
 WHITE

 B7219014
 B721901

B7219015



170X125 mm






WWW.SERAX.COM

Veldkant 21, 2550 Kontich, Belgium - Tel. +32 3 458 05 82

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference.


- 1. Take account of the minimal separation distance from other objects and the room required around the fitting.
- 2. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- 3. Meaning of symbols:

Œ



## Safety directions / Instruction manual Antonino Wall / Table Lamp Ombre

BLACK B7219016 WHITE B7219017



SERAX




WWW.SERAX.COM

Veldkant 21, 2550 Kontich, Belgium - Tel. +32 3 458 05 82

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference.


- 1. Take account of the minimal separation distance from other objects and the room required around the fitting.
- 2. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- 3. Meaning of symbols:

Œ



## Safety directions / Instruction manual Antonino Wall / Table Lamp Ombre

BLACK B7219018 WHITE B7219019



WWW.SERAX.COM

Max 25W 1xE14

SERAX

Veldkant 21, 2550 Kontich, Belgium - Tel. +32 3 458 05 82

Please study the instruction manual and below information carefully before installing or using this product. Please keep this user manual for further reference.

- 1. Take account of the minimal separation distance from other objects and the room required around the fitting.
- 2. If the external flexible cable or cord of this luminaire is damaged, it shall be exclusively replaced by the manufacturer or his service agent or a similar qualified person in order to avoid a hazard.
- 3. Meaning of symbols:

Œ

